



General Description

Junckers BASEPRIME is a quick-drying primer which in combination with Junckers solvent based or water based lacquers is suitable for most sanded and untreated parquet floors, including most exotic wood floors.

Junckers BASEPRIME gives light-coloured woods a light-gold appearance.

Junckers BASEPRIME should only be used as the sealing coat for the wood fibres.

Technical Data

Product:	Priming lacquer based on alcohol-solvent.
Package sizes:	5 litre and 10 litre.
Appearance:	Colourless.
Coverage:	10 m ² per litre.
Application tools:	Brush or short-pile varnishing roller. Do not apply by spraying.
Substrate temperature:	Minimum 10°C.
Dilution:	Delivered ready for use. Dilution is not recommended.
Drying time:	Dry to touch after approx. 15 min. at 20°C and 50 %RH.
Cleaning of tools:	Junckers Thinner 007.
Storage:	Lasts for 2 years if unopened and stored at 20°C. Not to be exposed to temperatures above 40°C.

System Recommendations

High traffic areas:	1 coat Junckers BASEPRIME 10 m ² /ltr. + 2 coats Junckers High Performance Commercial 10m ² ltr. or 1 coat Junckers BASEPRIME 10 m ² /ltr + 2 coats Junckers STRONG 10 m ² /ltr
Low traffic areas:	1 coat Junckers BASEPRIME 10 m ² /ltr + 1-2 coats Junckers PROTECH 10 m ² /ltr or 1 coat Junckers BASEPRIME 10 m ² /ltr + 2 coats Junckers PRO FINISH 10 m ² /ltr
Sport areas:	1 coat Junckers BASEPRIME 10 m ² ltr. + 2 coats Junckers HP SPORT 10m ² ltr

Directions for Use

Untreated/sanded floors:

The surface should be clean, dry and free from dust, wax, grease, polish etc. Machine sand the floor as advised under Previously lacquered floors to remove dirt and irregularities. The last sanding should be carried out by using minimum grit 100-120 before applying **Junckers BASEPRIME**. Thoroughly clean off the sanding dust (e.g. by vacuuming).

Apply **Junckers BASEPRIME** in an even layer with a varnishing roller or brush. Leave to dry properly before sanding and application of the following coat of lacquer. The system is build up according to the “**System recommendations**” and the recommendations for each individual product in the system.

Previously lacquered floors:

Machine sand before applying **Junckers BASEPRIME**. Use grit 24-36 to strip old coats. Then remove abrasion marks with grit 60-80. Finally, use grit 100-120 to obtain a completely smooth surface. Vacuum sanding dust and prime the floor as described under “**Untreated/ sanded floors**”.

Important!

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.

Important!

Stir well before use.

Further information

Products:

- F 4.2 - **Junckers PRO FINISH**
- F 5.1 - **Junckers STRONG**
- F 6.2 - **Junckers PRO TECH**
- F 7.5 - **Junckers Thinner 007**
- F 8.2 - **Junckers HP SPORT**
- F 8.5 - **Junckers High Performance Commercial**